

Microfilm Scanner 300/350 Instructions Supplement

Using USB Converter

When connecting MicrofilmScanner300/350 to the computer, below USB Converter can be used in addition to the SCSI connections mentioned on Page 18 of Instruction manual.

➤ **Recommended USB Converter**

- **Manufacturer:** Ratoc Systems, International
- **Model Name:** Ratoc USB2.0-UltraSCSI Converter U2SCX

➤ **Important**

- USB converters other than the above-mentioned may not be compatible.
- Multiple scanners connected in a daisy chain is not supported. If you want to connect multiple scanners, please use SCSI connection as described on Page 19 of Instruction manual.
- When scanning in high-resolution mode using USB converter, the scanning speed may be slower compared to when connected with SCSI.
- Switch on the MS300/350 connected to the computer before you switch on the computer. Otherwise, the MS300/350 may not operate properly.

Microfilm Scanner 300/350 補足説明書

USB コンバータの使用について

MicrofilmScanner300/350 をコンピュータに接続してスキャナとして使用する場合、取扱説明書 P18 に記載されている SCSI 接続に加え、以下の USB コンバータによる USB 接続でも使用することができます。

■ 推奨 USB コンバータ

- メーカー: ラトックシステム株式会社
- 品番: Ratoc USB2.0-UltraSCSI Converter U2SCX

■ ご注意

上記以外の USB コンバータでの動作は保証しません。

USB コンバータをご使用には以下の制限がありますのでご注意ください。

- マルチスキャナ接続はサポートしておりません。マルチスキャナ接続の際は SCSI 接続で使用するください。
- 高解像度でスキャンする場合、スキャンスピードが SCSI 接続時と比較し、遅くなる場合があります。
- 電源を入れるときは、必ず SCSI 接続の場合と同じ順番 (MS300/350→コンピュータ) で電源を入れてください。コンピュータの電源を入れてから、USB コンバータで接続されている MS300/350 の電源を入れると、MS300/350 が正常に動作しないことがあります。